



NOTES:

1. AFTER SUCCESSFUL MAIN TESTING AND DISINFECTION, REMOVE EXTENSION AND RISER. PLUG ELBOW.
2. TO EXTEND WATER MAIN, REMOVE REDUCER AND VALVE.

			TEMPORARY FLUSHING DEVICE DETAIL (BLOWOFF)	FIGURE: 5020.3
REV.	DATE	BY		SHEET 1 OF 1
DATE: 01-01-98				